


C3200B-9213

**C Plug Clamp Right Angle For RG213;
1.2GHz VSWR 1.2**

50Ω



Parts	Material	Plating(Micro-inch)
Body	Brass	Tin-Zinc-Copper-Alloy 100 Over Copper 50
Nut	Brass	Tin-Zinc-Copper-Alloy 100 Over Copper 50
Nut Hex	Brass	Tin-Zinc-Copper-Alloy 100 Over Copper 50
Gasket	Silicone	
Braid Clamp	Brass	Tin-Zinc-Copper-Alloy 100 Over Copper 50
Contact Pin	Brass	Gold 4 Over Nickel-Phosphorus Alloy 80 Over Copper 20
Spring	SK5	Tin-Zinc-Copper-Alloy 100 Over Copper 50
Washer	Brass	Tin-Zinc-Copper-Alloy 100 Over Copper 50
Insulator	Teflon	
Contact Body	Brass	Tin-Zinc-Copper-Alloy 100 Over Copper 50
Coupling Nut	Brass	Tin-Zinc-Copper-Alloy 100 Over Copper 50

Weight: 80.51 g

Suitable Cables: RG213

This part number complies with RoHS.








Notice: JYEBAO reserves the right to make modifications deemed appropriate.

C	C3200B-9213
Interface MIL-STD-348B	
Electrical Data Impedance 50Ω Frequency range DC to 1.2GHz VSWR ≤ 1.2 (DC to 1.2GHz) Insertion loss $\leq 0.1 \times \sqrt{f(\text{GHz})}$ dB Insulation resistance $\geq 10000\text{M}\Omega$ Contact resistance inner conductor $\leq 1\text{m}\Omega$ Contact resistance outer conductor $\leq 0.25\text{m}\Omega$ Dielectric withstanding voltage (at sea level) 3000 V rms Working Voltage (at sea level) 1000 V rms Power Handling $\leq 400\text{W}$ (1GHz)	
Mechanical Data 2 stud bayonet Coupling Per MIL-C-39012 Coupling nut retention force ≥ 100 lbs Contact Captivation-axial ≥ 6 lbs Durability (mating) ≥ 500	
Environmental Data Temperature range -65°C to +165°C Thermal shock MIL-STD-202, Method 107, Condition B Moisture resistance MIL-STD-202, Method 206 Corrosion MIL-STD-202, Method 101, Condition B RoHS Compliant	
Tooling	

Notice: JYEBAO reserves the right to make modifications deemed appropriate.

JYE BAO CO., LTD.

CABLE ASSEMBLY INSTRUCTION

C3200B-9213			DATE	2014/04/29	REV	—
A	B	C	D	E	F	
						
BODY	BRAID CLAMP	GASKET	WASHER	HEX NUT	NUT	
DIAGRAM			ASSEMBLY INSTRUCTION			
			Step 1: STRIP AS SHOWN.			
			Step 2: SLIDE NUT " E " 、 WASHER " D " 、 GASKET " C " AND BRAID CLAMP " B " OVER CABLE.			
			Step 3: WRAP THE BRAIDING OVER " B " .			
			Step 4: STRIP AS SHOWN.			
			Step 5: SCREW NUT " E " ON THE CONNECTOR BODY " A " AND SOLDER IN " Y " .			
			Step 6: FINALLY SCREW NUT " F " ON THE CONNECTOR BODY " A " .			
This part number complies with RoHS. Notice: JYEBAO reserves the right to make modifications deemed appropriate.						
APPROVED		CHECKED		DRAWING		
				Albert		

C3200B-9213

S11

