








7/16-3300-0250	7/16 Plug Solder	50Ω																											
<table border="1" style="width: 100%; border-collapse: collapse; text-align: center;"> <thead> <tr> <th style="width: 15%;">Parts</th> <th style="width: 15%;">Material</th> <th style="width: 70%;">Plating(Micro-inch)</th> </tr> </thead> <tbody> <tr> <td>Nut</td> <td>Brass</td> <td>Tin-Zinc-Copper-Alloy 100 Over Copper 50</td> </tr> <tr> <td>Ferrule</td> <td>Brass</td> <td>Gold 5 Over Nickel 50 Over Copper 50</td> </tr> <tr> <td>Contact Pin</td> <td>Phosphor Bronze</td> <td>Silver 150 Over Copper 50</td> </tr> <tr> <td>Gasket</td> <td>Silicon</td> <td></td> </tr> <tr> <td>Retainer Ring</td> <td>Brass</td> <td>Tin-Zinc-Copper-Alloy 100 Over Copper 50</td> </tr> <tr> <td>Insulator</td> <td>Teflon</td> <td></td> </tr> <tr> <td>Body</td> <td>Brass</td> <td>Tin-Zinc-Copper-Alloy 100 Over Copper 50</td> </tr> <tr> <td>Coupling Nut</td> <td>Brass</td> <td>Tin-Zinc-Copper-Alloy 100 Over Copper 50</td> </tr> </tbody> </table>			Parts	Material	Plating(Micro-inch)	Nut	Brass	Tin-Zinc-Copper-Alloy 100 Over Copper 50	Ferrule	Brass	Gold 5 Over Nickel 50 Over Copper 50	Contact Pin	Phosphor Bronze	Silver 150 Over Copper 50	Gasket	Silicon		Retainer Ring	Brass	Tin-Zinc-Copper-Alloy 100 Over Copper 50	Insulator	Teflon		Body	Brass	Tin-Zinc-Copper-Alloy 100 Over Copper 50	Coupling Nut	Brass	Tin-Zinc-Copper-Alloy 100 Over Copper 50
Parts	Material	Plating(Micro-inch)																											
Nut	Brass	Tin-Zinc-Copper-Alloy 100 Over Copper 50																											
Ferrule	Brass	Gold 5 Over Nickel 50 Over Copper 50																											
Contact Pin	Phosphor Bronze	Silver 150 Over Copper 50																											
Gasket	Silicon																												
Retainer Ring	Brass	Tin-Zinc-Copper-Alloy 100 Over Copper 50																											
Insulator	Teflon																												
Body	Brass	Tin-Zinc-Copper-Alloy 100 Over Copper 50																											
Coupling Nut	Brass	Tin-Zinc-Copper-Alloy 100 Over Copper 50																											
Weight: 110 g Suitable Cables: Semi-rigid.250																													

This part number complies with RoHS.
Notice: JYEBAO reserves the right to make modifications deemed appropriate.

JYE BAO CO., LTD.

CABLE ASSEMBLY INSTRUCTION

7/16-3300-0250	DATE	2018/06/01	REV	—
A	B	C		
				
BODY	FERRULE	NUT		
DIAGRAM	ASSEMBLY INSTRUCTION			
	Step 1: STRIP AS SHOWN.			
	Step 2: SHARPEN CENTER CONDUCTOR TIP.			
	Step 3: SLIDE NUT " C " AND FERRULE " B " OVER CABLE AND SOLDER IN " Y ". Step 5: CUT EXCESS TEFLON AFTER SOLDERING .			
	Step 5: FINALLY SCREW NUT " C " ON THE CONNECTOR BODY " A ".			
<p>This part number complies with RoHS.</p> <p>Notice: JYEBAO reserves the right to make modifications deemed appropriate.</p>				
APPROVED	CHECKED	DRAWING	<i>Albert</i>	